

### Freescale Semiconductor Engineering Bulletin

Document Number: EB676 Rev. 0, 02/2007

# **M5275 Evaluation Board Errata**

1

by: Microcontroller Division

This document identifies implementation differences between the M5275EVB and M5275EVBE and the description contained in the M5275EVB User's Manual. Check http://www.freescale.com for the latest updates.

This document applies to all revisions of the M5275EVB and M5275EVBE.

#### Contents

ASE	RAM
1.1	Description of Problem
1.2	Solution



© Freescale Semiconductor, Inc., 2007. All rights reserved.



# 1 ASRAM

# 1.1 Description of Problem

The EVB has a footprint for one 256 Kbytes  $\times$  16 asynchronous SRAM devices (Cypress Semiconductor – CY7C1041CV3310ZC). This memory device (U1) may be populated for benchmarking purposes. However, the EVBs have incorrectly interfaced to the ASRAM where addressing to (U1) is mapped [A0:A17] to the MCF5275's (U6) buffered address signals [B\_A2:B\_A19]. This is shown in Figure 1.




Figure 1. Example of Incorrect ASRAM Interface Found on EVBs

# 1.2 Solution

The EVBs should be interfaced to the ASRAM where addressing to (U1) is mapped [A0:A17] to the MCF5275's (U6) buffered address signals [B\_A1:B\_A18]. This is shown below in Figure 2.






Figure 2. Example of Correct ASRAM Interface Found on EVBs.

The corrected addressing implementation is on the next revision of the evaluation board, M5275EVBE Rev. B.



#### How to Reach Us:

Home Page: www.freescale.com

#### Web Support:

http://www.freescale.com/support

#### USA/Europe or Locations Not Listed:

Freescale Semiconductor, Inc. Technical Information Center, EL516 2100 East Elliot Road Tempe, Arizona 85284 +1-800-521-6274 or +1-480-768-2130 www.freescale.com/support

#### Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH Technical Information Center Schatzbogen 7 81829 Muenchen, Germany +44 1296 380 456 (English) +46 8 52200080 (English) +49 89 92103 559 (German) +33 1 69 35 48 48 (French) www.freescale.com/support

#### Japan:

Freescale Semiconductor Japan Ltd. Headquarters ARCO Tower 15F 1-8-1, Shimo-Meguro, Meguro-ku, Tokyo 153-0064 Japan 0120 191014 or +81 3 5437 9125 support.japan@freescale.com

#### Asia/Pacific:

Freescale Semiconductor Hong Kong Ltd. Technical Information Center 2 Dai King Street Tai Po Industrial Estate Tai Po, N.T., Hong Kong +800 2666 8080 support.asia@freescale.com

For Literature Requests Only: Freescale Semiconductor Literature Distribution Center P.O. Box 5405 Denver, Colorado 80217 1-800-441-2447 or 303-675-2140 Fax: 303-675-2150 LDCForFreescaleSemiconductor@hibbertgroup.com

Document Number: EB676 Rev. 0 02/2007 Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

RoHS-compliant and/or Pb-free versions of Freescale products have the functionality and electrical characteristics as their non-RoHS-compliant and/or non-Pb-free counterparts. For further information, see http://www.freescale.com or contact your Freescale sales representative.

For information on Freescale's Environmental Products program, go to http://www.freescale.com/epp.

Freescale<sup>™</sup> and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners. © Freescale Semiconductor, Inc. 2007. All rights reserved.

