

# VLE 16-bit and 32-bit Instruction Length Decode Algorithm

by: Pavel Bohacik

## Contents

## 1 Introduction

The MPC56xx 32-bit microcontroller family built on Power Architecture® technology provides a mechanism by which the e200 core implements interrupts and exceptions. This application note describes a method for decoding the length of VLE instructions, one which is used to correctly increment the returning address of the exception.

## 2 Overview

In this application note, core exceptions are split into two types:

- Exceptions for which the address located in the SRR0 is increased automatically.
- Exceptions for which the address located in the SRR0 has to be increased manually based on the length of the instruction that caused the exception.

This information is located in the IVORx interrupt chapter in the related *e200 Core Reference Manual*.

**Table 1** highlights IVORx exceptions that require manual incrementing of the return address in the SRR0 register for the e200z7 core. For further information, refer to the "Debug

1	Introduction.....	1
2	Overview.....	1
3	Machine check interrupt (IVOR1 exception) example.....	2
4	Book E or VLE instruction decoding.....	2
5	Decoding 16-bit or 32-bit VLE instructions.....	3
5.1	Decoding the condition in C.....	4
5.2	Decoding the condition in assembly.....	5
6	Conclusion.....	5
7	References.....	5



## Machine check interrupt (IVOR1 exception) example

Interrupt—Register Settings" table in the Interrupts and Exceptions chapter of document number e200z760RM, *e200z760n3 Power Architecture Core Reference Manual*.

**Table 1. SRR0 register behavior for each IVORx exception (e200z7 core)**

IVORx number	IVORx name	SRR0, CSSSR, DSSSR0, MCSRR0 register behavior
IVOR0	Critical input interrupt	Set to the effective address of the instruction that the processor would have attempted to execute next if no exception conditions were present.
IVOR1	Machine check interrupt	On a best-effort basis, e200 sets this to the address of the instruction that was executing or about to be executed when the machine check condition occurred.
IVOR2	Data storage interrupt	Set to the effective address of the excepting load/store instruction.
IVOR3	Instruction storage interrupt	Set to the effective address of the excepting instruction.
IVOR5	Alignment interrupt	Set to the effective address of the excepting load/store instruction.
IVOR6	Program interrupt	Set to the effective address of the excepting instruction.
IVOR7	Floating-point unavailable interrupt	Set to the effective address of the excepting instruction.
IVOR13	Data TLB error interrupt	Set to the effective address of the excepting load/store instruction.
IVOR14	Instruction TLB error interrupt	Set to the effective address of the excepting instruction.
IVOR15	Debug interrupt	Set to the effective address of the excepting instruction or next instruction to be executed.
IVOR32	SPE/EFPU unavailable interrupt	Set to the effective address of the excepting SPE/EFPU instruction.
IVOR33	Embedded floating-point data interrupt	Set to the effective address of the excepting EFPU instruction.

## 3 Machine check interrupt (IVOR1 exception) example

When an IVOR1 exception occurs (due to memory protection, for example), the e200 core sets Machine Check Save/Restore Register 0 (MCSRR0) to the address of the instruction that was executed or about to be executed when the machine check condition occurred. If a recoverable machine check exception occurred, you should update MCSSR0 appropriately in the IVOR1 handler epilog based on all recommendations mentioned in AN2865, *Qorivva Simple Cookbook* available at [freescale.com](http://freescale.com).

Freescall e200 cores allow you to use both variable length encoding (VLE) 16-bit and 32-bit instructions and Book E 32-bit instructions. (Book E is not supported by the e200z0 core, however.) When a machine check interrupt occurs, MCSRR0 contains the address of the instruction that was executed when the machine check occurred. To avoid a recurrence of the machine check interrupt, you should properly increment the instruction address in MCSSR0. The increment of the instruction address depends on the type of instruction interrupted by the machine check interrupt. An increment of 4 bytes is required for Book E instructions and VLE 32-bit instructions; an increment of 2 bytes is required for VLE 16-bit instructions.

## 4 Book E or VLE instruction decoding

More powerful types of e200 cores, like the e200z7, allow a mixed execution of VLE and Book E instructions. For this reason, Book E instruction detection is required when a machine check interrupt occurs.

There are several ways to determine whether a Book E or a VLE instruction was used.

1. Check Instruction Register Status Bit 8 in the Control State Register (CTL[IRSTAT8]) to determine the Power ISA VLE status for the Instruction Register (IR). This is a debug register, so it is not accessible by the main core. See e200z760RM, e200z760n3 *Power Architecture Core Reference Manual* for further details.

If CTL[IRSTAT8] is	Then the Instruction Register contains a
0	Book E instruction
1	Power ISA VLE instruction (aligned in the most significant portion of IR if 16-bit)

2. Check the Power ISA VLE bit in the Memory Management Unit's MMU Assist Register 2 to determine the type of page. Your IVORx epilog should read all valid MMU table entries (MAS1[VALID]) and compare whether the returning address located in Machine Status Save/Restore Register 0 (SRR0) fits one of MMU entries.

If MAS2[VLE] is	Then the page is a
0	Standard Book E page
1	Power ISA VLE page

3. Use a global variable. To simplify the procedure with the MMU, which may be undesired because it takes a significant amount of time, you can use a global array that lists memory ranges of VLE or Book E pages and is filled during the definition of MMU entries. Your IVORx epilog then reads SRR0 and determines whether a VLE or Book E instruction was executed based on global array values.

## 5 Decoding 16-bit or 32-bit VLE instructions

When a VLE instruction has been successfully decoded, the interrupt handler epilog should detect whether a 16-bit or 32-bit VLE instruction has been interrupted. Depending on the type of e200 core, different 32-bit instructions are available. See VLEPEM, *Variable-Length Encoding (VLE) Programming Environments Manual*, for the "VLE Instruction Set Sorted by Opcode" table, which contains both 32-bit and 16-bit instructions. After detailed investigation, the difference in opcode between all types of 16-bit and 32-bit VLE instructions is easily visible. Table 2, which lists a range of 16-bit and 32-bit VLE instructions, is based on the table from VLEPEM.

Opcode size is determined by the first 4 bits (instruction bus[0:3]). 16-bit operations use encoding 0b0xx0 and 0b1xxx, with the exception of 0b1111, which are reserved operations (32-bit). 32-bit operations use 0b0xx1. As highlighted in the following table, 32-bit instructions contain values 1, 3, 5, and 7 in the most significant byte position of this opcode. 16-bit VLE instruction contains values 0, 2, 4, 6, 8, 9, 0xA, 0xB, 0xC, 0xD, and 0xE in the most significant byte position of this opcode.

Table 2. 16- and 32-bit VLE instruction set ranges

Opcode (hexadecimal)	Category	Mnemonic	Instruction
0000----	16-bit VLE	se_illegal	Illegal
0001----	16-bit VLE	se_isync	Instruction Synchronize
...			
0F00----	16-bit VLE	se_cmphi	Compare Halfword Logical Short Form
10000000	32-bit VEC	vaddubm	Vector Add Unsigned Byte Modulo
10000002	32-bit VEC	vmaxub	Vector Maximum Unsigned Byte
...			

Table continues on the next page...

## Table 2. 16- and 32-bit VLE instruction set ranges (continued)

Opcode (hexadecimal)	Category	Mnemonic	Instruction
1C000000	32-bit VLE	e_add16i	Add Immediate
2000----	16-bit VLE	se_addi	Add Immediate Short Form
2200----	16-bit VLE	se_cmpli	Compare Logical Immediate Word
...			
2E00----	16-bit VLE	se_andi	AND Immediate Short Form
30000000	32-bit VLE	e_lbz	Load Byte and Zero
34000000	32-bit VLE	e_stb	Store Byte
38000000	32-bit VLE	e_lha	Load Halfword Algebraic
4000----	16-bit VLE	se_srw	Shift Right Word
4100----	16-bit VLE	se_sraw	Shift Right Algebraic Word RR 4200----
...			
4800----	16-bit VLE	se_li	Load Immediate Short Form
50000000	32-bit VLE	e_lwz	Load Word and Zero
54000000	32-bit VLE	e_stw	Store Word
...			
5C000000	32-bit VLE	e_sth	Store Halfword
6000----	16-bit VLE	se_bclri	Bit Clear Immediate
6200----	16-bit VLE	se_bgeni	Bit Generate Immediate
...			
6C00----	16-bit VLE	se_slwi	Shift Left Word Immediate Short Form
70000000	32-bit VLE	e_li	Load Immediate
70008800	32-bit VLE	e_add2i.	Add (2 operand) Immediate and Record
...			
7C100120	32-bit B	mtocrf	Move To One Condition Register Field
8000----	16-bit VLE	se_lbz	Load Byte and Zero Short Form
9000----	16-bit VLE	se_stb	Store Byte Short Form
A000----	16-bit VLE	se_lhz	Load Halfword and Zero Short Form
B000----	16-bit VLE	se_sth	Store Halfword Short Form
C000----	16-bit VLE	se_lwz	Load Word and Zero Short Form
D000----	16-bit VLE	se_stw	Store Word Short Form
E000----	16-bit VLE	se_bc	Branch Conditional Short Form
E800----	16-bit VLE	se_b[l]	Branch [and Link]

## 5.1 Decoding the condition in C

```
if(VLE_INSTRUCTION)
{
    if((instruction & 0x9000) == 0x1000)
    {
        // first 4 bits have a value of 1,3,5,7
        return address +=4; //instruction was 32-bit
    }
    else
    {
        // first 4 bits have a value of 0,2,4,6,8,9,A,B,C,D,E (and F, but F is reserved)
        return address +=2; //instruction was 16-bit
    }
}
```

## 5.2 Decoding the condition in assembly

```
mfsspr r5,570                # MCSRR0 -> r5
se_lhz r4,0(r5)              # determine opcode @ MCSRR0
e_andi. r3,r4,0x9000
e_cmpli 0x0,r3,0x1000        # check bit 31,28 only
e_bne __machine_check_adjust_for_16bit_opcode
se_addi r5,2                  # 0xx1 => 32 bit
__machine_check_adjust_for_16bit_opcode:
se_addi r5,2                  # all others just 16 bit long
mtspr 570,r5                  # save adjusted return address
```

## 6 Conclusion

This application note describes how to correctly increment the returning address for IVORx exceptions, which do not automatically increase it. Incrementing the returning address is required only for instructions that would cause this exception continuously, causing software to get stuck. You should always correctly handle the root cause of the IVORx exception before incrementing the returning address.

## 7 References

Document number	Title	Availability
e200z760RM	e200z760n3 Power Architecture Core Reference Manual	<a href="http://freescale.com">freescale.com</a>
VLEPEM	Variable-Length Encoding (VLE) Programming Environments Manual	
AN2865	Qorivva Simple Cookbook	

## **How to Reach Us:**

### **Home Page:**

[www.freescale.com](http://www.freescale.com)

### **Web Support:**

<http://www.freescale.com/support>

### **USA/Europe or Locations Not Listed:**

Freescale Semiconductor  
Technical Information Center, EL516  
2100 East Elliot Road  
Tempe, Arizona 85284  
+1-800-521-6274 or +1-480-768-2130  
[www.freescale.com/support](http://www.freescale.com/support)

### **Europe, Middle East, and Africa:**

Freescale Halbleiter Deutschland GmbH  
Technical Information Center  
Schatzbogen 7  
81829 Muenchen, Germany  
+44 1296 380 456 (English)  
+46 8 52200080 (English)  
+49 89 92103 559 (German)  
+33 1 69 35 48 48 (French)  
[www.freescale.com/support](http://www.freescale.com/support)

### **Japan:**

Freescale Semiconductor Japan Ltd.  
Headquarters  
ARCO Tower 15F  
1-8-1, Shimo-Meguro, Meguro-ku,  
Tokyo 153-0064  
Japan  
0120 191014 or +81 3 5437 9125  
[support.japan@freescale.com](mailto:support.japan@freescale.com)

### **Asia/Pacific:**

Freescale Semiconductor China Ltd.  
Exchange Building 23F  
No. 118 Jianguo Road  
Chaoyang District  
Beijing 100022  
China  
+86 10 5879 8000  
[support.asia@freescale.com](mailto:support.asia@freescale.com)

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductors products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claims alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

RoHS-compliant and/or Pb-free versions of Freescale products have the functionality and electrical characteristics as their non-RoHS-complaint and/or non-Pb-free counterparts. For further information, see <http://www.freescale.com> or contact your Freescale sales representative.

For information on Freescale's Environmental Products program, go to <http://www.freescale.com/epp>.

Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.

© 2013 Freescale Semiconductor, Inc.